



Down With Dirty Phonograph Record Cleaning Concentrate Formula

Down With Dirty from **Audio Intelligent Vinyl Solutions** is a concentrate that is mixed with distilled water to make a ready-to-use record cleaning formula that is safe, effective, and economical. The **Down With Dirty** concentrate will make up to 27 quarts of ready-to-use formula.

The **Down With Dirty** kit includes a 16 ounce bottle of **Down With Dirty** record cleaning concentrate, one empty 16 ounce bottle with cap, and one plastic measuring cup.

Please follow the instructions below for best results.

1. The empty 16 ounce bottle is for your ready-to-use formula. Thoroughly rinse it and the bottle cap before use and also every time before refilling it.
2. Put 16 ounces of distilled water in the empty bottle. **DO NOT USE TAP WATER OR BOTTLED DRINKING WATER. THEY CONTAIN TRACE MINERALS AND ARE NOT PURE ENOUGH TO ACHIEVE MAXIMUM CLEANING RESULTS.**
3. For normal strength, measure out 10 milliliters of concentrate using the supplied measuring cup and pour into the bottle with the distilled water. Screw on the cap and swirl the contents of the bottle to mix. Swirl the bottle before each cleaning session to ensure product is mixed.
4. For pre-cleaning and tough cleaning jobs, up to 20 milliliters of concentrate can be used per 16 ounces of distilled water. However, at this concentration rinsing with distilled water as a follow-up step is recommended.

February 2020

Tips For Cleaning Your Records With Audio Intelligent Vinyl Solutions Products.

1. Always store your Audio Intelligent Vinyl Solutions products in their original bottles with the flip spouts closed. The HDPE (high-density polyethylene) bottles are designed to preserve the fluids for several years.
2. Store your Audio Intelligent Vinyl Solutions products away from heat, cold, and direct sunlight. Keep them away from children.
3. Rinse your brushes frequently using reverse osmosis processed water, or distilled water.
4. When hand cleaning, always use soft, lint-free cotton toweling or cloths for drying the record. These products are available in photography supply shops and can be found on the internet and in kitchen stores as well. Most synthetic micro-fiber towels are NOT lint-free and will deposit small particles of lint on the record.
5. NEVER employ hard scrubbing when cleaning any record with any record cleaning product. Doing so can result in a record that is much more difficult to thoroughly clean and can cause permanent damage to the record.
6. Audio Intelligent Vinyl Solutions products are for hand cleaning and vacuum cleaning only and are not recommended for use in bath vat or ultrasonic record cleaning machines.
7. Always check the stylus on your cartridge for a ball or glob of residue after playback of a record. IF YOU FIND ANYTHING OTHER THAN DUST OR LINT, YOUR RECORD IS NOT CLEAN. This is an indication that contaminants are present on your record or that a lubricant is present.

Warnings and Cautions

Keep all Audio Intelligent Vinyl Solutions formulas out of the reach of children. Please read and follow all warnings and instructions on the individual product labels.

Audio Intelligent Vinyl Solutions products should not be ingested and prolonged contact with the skin should be avoided.

If you get any of the formulas in your eyes or nose, seek medical attention immediately.

Manufactured in USA and Distributed by Osage Audio Products, LLC
P.O. Box 232 • Hallsville, MO 65255 • 573-696-3551
www.osageaudio.com • www.audiointelligent.com